


LISTA DE REPUESTOS :- BARRENA DE TIERRA/SPARE PARTS LIST:- EARTH AUGER




MODELO/MODEL : BON-P-EA52



















LISTA DE PARTES DEL CUERPO (BODY PART LIST)









S. No	ERP - CODE	BOHNOEFFER CODIGO	DESCRIPTION IN ENGLISH	DESCRIPCION EN ESPANOL	FOTO	CANTIDAD REQUERIDA	Unit Price	Total Price
-------	------------	-------------------	------------------------	------------------------	------	--------------------	------------	-------------




















1	T.BCE26B.05.3	BONEA52-B01	AIR FILTER KNOB	PERILLA DEL FILTRO DE AIRE				
2	T.BCI43-02	BONEA52-B02	AIR FILTER OUTER COVER	CUBIERTA EXTERIOR DEL FILTRO DE AIRE				
3	T.BCB43.01-3	BONEA52-B03	AIR FILTER INNER COVER	TAPA INTERIOR DEL FILTRO DE AIRE				

4	T.BCB43.01-2	BONEA52-B04	AIR FILTER SPONGE	ESPONJA DE FILTRO DE AIRE				
5	GB/T 70.1	BONEA52-B05	M5X60 SCREW	TORNILLO M5X60				
6	GB/T 93	BONEA52-B06	SPRING WASHER 5	ARANDELA ELÁSTICA 5				
7	GB/T 97.1	BONEA52-B07	FLAT WASHER 5	ARANDELA PLANA 5				
8	T.BCB43.01-1	BONEA52-B08	FILTER AIR BRACKET	SOPORTE DE FILTRO DE AIRE				
9	T.BCB43.01.1	BONEA52-B09	AIR FILTER BASE	BASE DEL FILTRO DE AIRE				
10	T.BCE43-005A	BONEA52-B10	FRONT-HALF CRANKSHAFT CASE	CAJA DEL CIGÜEÑAL DE LA MITAD DELANTERA				
11	5011.31401	BONEA52-B11	CARBURATOR	CARBURADOR				











12	T.BCB43-003	BONEA52-B12	CARBURATOR GASKET	JUNTA DE CARBURADOR				
13	GB/T 70.1	BONEA52-B13	M5X25 HEX SCREW	TORNILLO HEXAGONAL M5X25				
14	T.BCB43-007	BONEA52-B14	INLET PIPE	TUBO DE ENTRADA				
15	T.BCB43-002	BONEA52-B15	INLET PIPE GASKET	JUNTA DE TUBO DE ENTRADA				
16	T.BCE43-004	BONEA52-B16	CYLINDER	CILINDRO				
17	GB/T 119.2	BONEA52-B17	ROUND PIN B5X10	PASADOR REDONDO B5X10				
18	5011.34601	BONEA52-B18	MUFFLER GASKET ASSY.	CONJUNTO DE JUNTA DE SILENCIADOR.				
19	T.BCS45.05A	BONEA52-B19	MUFFLER	SILENCIADOR				










21	GB/T 97.1	BONEA52-B21	FLAT WASHER 6	ARANDELA PLANA 6				
22	GB/T 70.1	BONEA52-B22	M5X12 HEX SCREW	TORNILLO HEXAGONAL M5X12				
23	GB/T 70.1	BONEA52-B23	M6X60 CREW	TRIPULACIÓN M6X60				
24	GB/T 70.1	BONEA52-B24	M5X16 HEX SCREW	TORNILLO HEXAGONAL M5X16				
25	T.BCI43-03	BONEA52-B25	TOP COVER	LA CUBIERTA SUPERIOR				
26	T.EA52I-01	BONEA52-B26	ENGINE CASE COVER	CUBIERTA DE LA CAJA DEL MOTOR				
27	T.BCI43-04	BONEA52-B27	WINDSHIELD	PARABRISAS				
28	GB/T 845	BONEA52-B28	ST3X9-H-C SCREW	TORNILLO ST3X9-H-C				











29	GB/T 70.1	BONEA52-B29	M5X20 HEX SCREW	TORNILLO HEXAGONAL M5X20				
30	T.BCE26-010	BONEA52-B30	SPARK PLUG	BUJÍA				
31	T.BCB43-004	BONEA52-B31	CYLINDER GASKET	JUNTA DE CILINDRO				
32	5004.33206	BONEA52-B32	PISTON RING	ANILLO DE PISTÓN				
33	5011.33203	BONEA52-B33	PISTON	PISTÓN				
34	324010101	BONEA52-B34	PISTON PIN CHECKING RING	ANILLO DE CONTROL DEL BULÓN DEL PISTÓN				
35	5004.33209	BONEA52-B35	PISTON PIN	PASADOR DEL PISTÓN				
36	JB/T 7918	BONEA52-B36	NEEDLE BEARING KBK10X13X15.5	RODAMIENTO DE AGUJAS KBK10X13X15.5				










37	GB/T 1099	BONEA52-B37	HALF-ROUND KEY3*5*13	LLAVE SEMICIRCULAR 3*5*13				
38	GB/T 9877.1	BONEA52-B38	OIL SEAL TC15X30X7	SELLO DE ACEITE TC15X30X7				
39	GB/T 276	BONEA52-B39	BEARING 6202	COJINETE 6202				
40	5011.31905	BONEA52-B40	CRANKSHAFT	CIGÜEÑAL				
41	GB/T 9877.1	BONEA52-B41	OIL SEAL TC12X22X7	SELLO DE ACEITE TC12X22X7				
42	T.BCB43-005	BONEA52-B42	CRANKCASE GASKET	JUNTA DE CÁRTER				
43	T.BCE43-006A	BONEA52-B43	BACK-HALF CRANKSHAFT CASE	CAJA DEL CIGÜEÑAL DE LA MITAD TRASERA				
44	T.BCE33B.09	BONEA52-B44	STARTER CATCH PLATE ASSY	CONJUNTO DE PLACA DE ARRANQUE				
45	GB/T 6170	BONEA52-B45	M8 NUT	TUERCA M8				

46	T.BCB33-060	BONEA52-B46	STARTER GASKET	JUNTA DE ARRANQUE				
47	T.BCI43.01	BONEA52-B47	STARTER ASSY	CONJUNTO DE ARRANQUE				
48	5011.33302	BONEA52-B48	FUEL TANK HOLDING PLATE	PLACA DE SUJECIÓN DEL TANQUE DE COMBUSTIBLE				
49	T.BCB33-051	BONEA52-B49	HOLDING PLATE RUBBER GASKET	JUNTA DE GOMA DE LA PLACA DE SUJECIÓN				
50	GB/T 70.1	BONEA52-B50	M5X20 SCREW	TORNILLO M5X20				
51	T.BCE43.10	BONEA52-B51	FUEL TANK ASSY.	CONJUNTO DE TANQUE DE COMBUSTIBLE.				
52	GB/T 70.1	BONEA52-B52	M5X30 HEX SCREW	TORNILLO HEXAGONAL M5X30				
53	5011.31903	BONEA52-B53	FLYWHEEL	VOLANTE				
54	GB/T 97.1	BONEA52-B54	FLAT WASHER 8	ARANDELA PLANA 8				

55	GB/T 93	BONEA52-B55	SPRING WASHER 8	ARANDELA ELÁSTICA 8				
56	5011.31101	BONEA52-B56	IGNITION COIL	BOBINA DE ENCENDIDO				
57	GB/T 119.2	BONEA52-B57	ROUND PIN B4X10	PASADOR REDONDO B4X10				
58	T.BCE43-003A	BONEA52-B58	FLYWHEEL COVER	CUBIERTA DEL VOLANTE				
59	T.BCB33-064	BONEA52-B59	WASHER B	ARANDELA B				
60	T.BCB33.10	BONEA52-B60	CLUTCH	EMBRAGUE				
61	T.BCB33-063	BONEA52-B61	WAVE WASHER	ARANDELA ONDULADA				
62	5003.3321	BONEA52-B62	SCREW AXES	EJES DE TORNILLO				
63	T.EA52I.01.2	BONEA52-B63	GEARCASE ASSY.	CONJUNTO DE CAJA DE CAMBIOS.				
64	T.EA52I.01.2-1	BONEA52-B63.1	CLUTH DRUM	TAMBOR DE EMBRAGUE				




65	T.EA52I.01.2-2	BONEA52-B63.2	UPPER GEARCASE HOUSING	CAJA DE ENGRANAJES SUPERIOR				
66	T.EA52I.01.2-3	BONEA52-B63.3	MIDDLE GEARCASE HOUSING	CAJA DE ENGRANAJES INTERMEDIA				
67	T.EA52I.01.2-4	BONEA52-B63.4	UPPER GEARCASE HOUSING SEAL	SELLO SUPERIOR DE LA CARCASA DE LA CAJA DE ENGRANAJES				
68	T.EA52I.01.2-5	BONEA52-B63.5	MIDDLE GEARCASE HOUSING SEAL	SELLO DE LA CARCASA DE LA CAJA DE ENGRANAJES INTERMEDIA				
69	T.EA52I.01.2-6	BONEA52-B63.6	LOWER GEARCASE HOUSING	CAJA DE ENGRANAJES INFERIOR				
70	GB/T9877.1	BONEA52-B63.7	OIL SEAL TC20X45X7	SELLO DE ACEITE TC20X45X7				
71	T.EA52I.01.2-7	BONEA52-B63.8	OUTPUT SHAFT	EJE DE SALIDA				
72	GB/T 276	BONEA52-B63.9	BEARING 6004-2RS	COJINETE 6004-2RS				
73	T.EA52I.01.2-8	BONEA52-B63.10	SP-47 GEAR	ENGRANAJE SP-47				
74	T.EA52I.01.2-9	BONEA52-B63.11	SP-10 GEAR SHAFT	EJE DE ENGRANAJE SP-10				





75	T.EA521.01.2-10	BONEA52-B63.12	SP-45 GEAR	ENGRANAJE SP-45				
76	GB/T276	BONEA52-B63.13	BEARING 6301-2RS	COJINETE 6301-2RS				
77	T.EA521.01.2-11	BONEA52-B63.14	SP-18 GEAR SHAFT	EJE DE ENGRANAJE SP-18				
78	GB/T276	BONEA52-B63.15	BEARING 6201-2RS	COJINETE 6201-2RS				
79	GB/T276	BONEA52-B63.16	BEARING 6201	TENIENDO 6201				
80	GB/T70.1	BONEA52-B63.17	M5X40 HEX SCREW	TORNILLO HEXAGONAL M5X40				
81	GB/T 70.1	BONEA52-B63.18	M5X25 HEX SCREW	TORNILLO HEXAGONAL M5X25				
82	T.EA521.01.2.1	BONEA52-B63.19	M6 GREASE FITTING	ENGRASADOR M6				
83	GB/T 119.2	BONEA52-B63.20	ROUND PIN B5X10	PASADOR REDONDO B5X10				
84	GB/T893.1	BONEA52-B63.21	Φ42 CHECK RING	ANILLO DE RETENCIÓN Φ42				

85	GB/T894.1	BONEA52-B63.22	Φ16 CHECK RING	ANILLO DE RETENCIÓN Φ16				
86	GB/T894.1	BONEA52-B63.23	Φ417 CHECK RING	ANILLO DE CONTROL Φ417				
87	T.EA52I.01.1	BONEA52-B64	HANDLE FRAME ASSY.	CONJUNTO DE MARCO DE MANIJA.				
88	T.EA52I.01-1	BONEA52-B65	BACKING PLATE	PLACA DE APOYO				
89	T.EA52I.01-2	BONEA52-B66	DAMPLING PLATE	PLACA AMORTIGUADORA				
90	GB/T5287	BONEA52-B67	BIG FLAT WASHER 6	ARANDELA PLANA GRANDE 6				
91	GB/T93	BONEA52-B68	SPRING WASHER 6	ARANDELA ELÁSTICA 6				
92	GB/T 70.1	BONEA52-B69	M6X60 CREW	TRIPULACIÓN M6X60				
93	GB/T70.1	BONEA52-B70	M6X25 HEX CREW	TRIPULACIÓN HEXAGONAL M6X25				

LISTA DE PIEZAS DEL TALADRO (DRILL PART LIST)

S. No	ERP - CODE	BOHNOEFFER CODIGO	DESCRIPTION IN ENGLISH	DESCRIPCION EN ESPAÑOL	FOTO	CANTIDAD REQUERIDA	Unit Price	Total Price
-------	------------	----------------------	---------------------------	---------------------------	------	-----------------------	------------	-------------



1	T.EA52I.02-1	BONEA52-D1.1.1	100MM (DIAMETER) X1000MM	100 MM (DIÁMETRO) X 1000 MM				
2	T.EA52I.02-2	BONEA52-D1.1.2	150MM (DIAMETER) X1000MM	150 MM (DIÁMETRO) X 1000 MM				
3	T.EA52I.02-3	BONEA52-D1.1.3	200MM (DIAMETER) X1000MM	200 MM (DIÁMETRO) X 1000 MM				
4	GB/T882	BONEA52-D1.2	CONNECTOR PIN Φ8X40	CLAVIJA DEL CONECTOR Φ8X40				
5	GB/T91	BONEA52-D1.3	CONNECTOR PIN LOCK	BLOQUEO DEL PIN DEL CONECTOR	