



# ENGINE 2 STROKE HIGH ROTATION PARTS

 <p><b>1 BON2S52WP-001</b> Enchufar Plug</p>	<p><b>2 BON2S52WP-005</b> Toma de corriente Outlet</p> 	 <p><b>3 BON2S52WP-007</b> Caja Casing</p>	<p><b>4 BON2S52WP-009</b> Entrada Inlet</p> 
 <p><b>5 BON2S52WP-014</b> Impulso Impeller</p>	<p><b>6 BON2S52WP-015</b> Sello del impulsor Impeller seal</p> 	 <p><b>7 BON2S52WP-018</b> Sello de la bomba Pump seal</p>	<p><b>8 BON2S52WP-020</b> El cuerpo de la bomba The body of pump</p> 
 <p><b>9 BON2S52WP-023</b> Bastidor de la bomba Pump frame</p>	<p><b>10 BON2S52WP-024</b> 15 retenedor exterior 15 outer retainer</p> 	 <p><b>11 BON2S52WP-029</b> Cable del acelerador Throttle cable</p>	
		